

# Work Order ID 75709

\*75709\*

Page 1

Friday, October 28, 2011 11:48:03 AM

Item ID: D206-642-114 Accept \*N900040100\* Setup Start \*NS1\*  
 Revision ID: Stop \*NS2\*  
 Item Name: Skidtube RH  
 Start Date: 10/28/2011 Start Qty: 1.00 \*1\* Cust Item ID:  
 Required Date: 12/15/2011 Req'd Qty: 1.00 \*1\* Customer:

## Reference:

Approvals: Process Plan:                      Date: 11-10-28 Tooling:                      Date:                      Run Start \*NR1\*  
 QC:                      Date:                      SPC (Y/N):                      Date:                      Stop \*NR2\*

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
--------------------------------	--------------------------	----------------------	---------	--------	--------------	---------------	---------------	------------------	----------------

Draw Nbr	Revision Nbr
IIN-D206-642	O

100 0.00 M.L.J 11/11/15

\*100\* DOCUMENT CONTROL

DC Memo 0.00

Document Control Photocopy bluefile & type labels per PPP206-642-114 CHG001

K10112 CHG002

CHG003

110 Pick Kit 0.00

\*110\*

Packaging Memo 0.00

Packaging

120 QC4- 100% Inspect kits for completeness 0.00

\*120\*

QC Memo 0.00

Quality Control

75488.

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: \_\_\_\_\_ PAR #: \_\_\_\_\_ Fault Category: \_\_\_\_\_ NCR: Yes No DQA: \_\_\_\_\_ Date: \_\_\_\_\_

Resolution: \_\_\_\_\_ Disposition: \_\_\_\_\_ QA: N/C Closed: \_\_\_\_\_ Date: \_\_\_\_\_

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

**NOTE:** Date & initial all entries

# Work Order ID 75709

**\*75709\***

Page 2

Friday, October 28, 2011 11:48:03 AM

Item ID: D206-642-114 Accept **\*N900040100\*** Setup Start **\*NS1\***  
 Revision ID: Stop **\*NS2\***  
 Item Name: Skidtube RH  
 Start Date: 10/28/2011 Start Qty: 1.00 **\*1\*** Cust Item ID:  
 Required Date: 12/15/2011 Req'd Qty: 1.00 **\*1\*** Customer:  
 Reference:

Approvals: Process Plan: \_\_\_\_\_ Date: \_\_\_\_\_ Tooling: \_\_\_\_\_ Date: \_\_\_\_\_ Run Start **\*NR1\***  
 QC: \_\_\_\_\_ Date: \_\_\_\_\_ SPC (Y/N): \_\_\_\_\_ Date: \_\_\_\_\_ Stop **\*NR2\***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
130		0.00							
<b>*130*</b>	Packaging								
Packaging	Memo	0.00							
Packaging	Identify and pack for shipping as per PPPD206-642-114								
	K10112								
	Location: <u>AR</u>								
	PPP Rev: <u>A</u>								
140		0.00							
<b>*140*</b>	QC21- Final Inspection - Work Order Release								
QC	Memo	0.00							
Quality Control									

SP 11-12-14

11/12/14

ME 11-12-14

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: \_\_\_\_\_ PAR #: \_\_\_\_\_ Fault Category: \_\_\_\_\_ NCR: Yes No DQA: \_\_\_\_\_ Date: \_\_\_\_\_

Resolution: \_\_\_\_\_ Disposition: \_\_\_\_\_ QA: N/C Closed: \_\_\_\_\_ Date: \_\_\_\_\_

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

**NOTE:** Date & initial all entries

# Picklist Print

Friday, October 28, 2011 11:48:07 AM

Page 1

Work Order ID: 75709

\*75709\*

Parent Item: D206-642-114

\*D206-642-114\*

Parent Item Name: Skidtube RH

Start Date: 10/28/2011

Required Date: 12/15/2011

Start Qty: 1.00

Required Qty: 1.00

Comments: IPP REV:A 10.12.08 PER REV:N DD VERF:EC  
11.09.23 ADDED K10112 DD VERF:EC

IPP REV:B

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
D206-642-151		Manufactured	No			110	Each	0.0000	1	1			
*D206-642-151*									**	BTS 403			
Replacement Skidtube													
K10112		Manufactured	No			110	Each	0.0000	1	1			
*K10112*									**	B76636			
Saddle, Skidtube 206													

SP.

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: \_\_\_\_\_ PAR #: \_\_\_\_\_ Fault Category: \_\_\_\_\_ NCR: Yes No DQA: \_\_\_\_\_ Date: \_\_\_\_\_

Resolution: \_\_\_\_\_ Disposition: \_\_\_\_\_ QA: N/C Closed: \_\_\_\_\_ Date: \_\_\_\_\_

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

**NOTE:** Date & initial all entries